# Kodak PIXPRO AZ362

Digital Camera

User Manual



### **BEFORE YOU START**

#### **Declaration of Conformity**

Responsible Party: JK Imaging Ltd.

Address: JK Imaging Ltd., 17239 South Main Street,

Gardena, CA 90248, USA

JK Imaging Europe, 71 Clarendon road,

Watford, WD17 1DS, UK

Company Website: www.kodakpixpro.com

For Customers in the U.S.A.

## Tested to Comply with FCC Standards FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### For Customers in Europe

CE" mark indicates that this product complies with the European requirements for safety, health, environment and customer protection. "CE" marked cameras are intended for sales in Europe.



This symbol [crossed-out wheel bin WEEE Annex IV] indicates separate collection of electrical waste and electronic equipment in the European countries. Please do not throw the equipment into domestic refuse. Please use the return and collection systems available in your country for proper, safe disposal of this product.

#### **About this Manual**

Thank you for purchasing this KODAK PIXPRO Digital Camera. Please read this manual carefully and keep it in a safe place for future reference.

- JK Imaging Ltd. reserves all rights of this document. No part of this published manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form, by any means, without the prior written permission of JK Imaging Ltd..
- All trademarks mentioned in this manual are used for identification purposes only and are properties of their respective owners.
- This manual provides you with instructions on how to use your new KODAK PIXPRO Digital Camera. Every effort has been made to ensure that the contents of this manual are accurate, however JK Imaging Ltd. reserves the right to make changes without notice.
- Throughout this manual, the following symbols are used to help you locate information quickly and easily:



Indicates useful information.



Indicates precautions are to be taken while operating the camera.

### SAFETY NOTES

#### Safety notes for this camera

- Do not drop the camera or allow it to hit solid objects.
- Do not attempt to disassemble the camera.
- To prevent the camera from being damaged by moisture, do not use or store the camera in very humid environments, such as in rain or near bodies of water.
- Do not use or store the camera in dusty places or on a beach to prevent dust or sand from entering the camera, causing possible damage to it.
- Do not use or store the camera in a hot environment or under direct sunlight.
- Do not use or store the camera near a powerful magnetic field, for example near a magnet or transformer.
- Avoid touching the lens of the camera.
- Do not expose the camera to direct sunlight for a long period time.
- Turn the camera off, remove the battery and the memory card, and dry it within 24 hours if water accidentally comes in contact with the camera.

- When you take the camera from a cold place to a warmer environment, condensation may occur. Please wait for a reasonable period of time before you turn it on.
- When you use the camera, remove the battery if it overheats. Wait until the unit cools down.
- Download your photos and remove the memory card when you are going to store the camera for a long period of time.
- Store the camera in a dry environment and place it on a flat surface when you are going to store the camera for a long period of time.
- Before you remove the battery and memory card, the camera should be turned off.
- When you clean the body of the camera, do not use abrasive, alcohol-based or organic cleaner.
- Use the professional lens wiping cloth and dedicated cleaner to wipe and clean the lens.

#### Safety notes for battery

- If the rechargeable Li-ion battery is used for the camera, only charge it with the supplied battery charger.
- If battery fluid leaks inside the camera, contact our customer service department.

- If battery fluid leaks onto your skin, rinse your skin with clean water and seek immediate medical attention.
- Disposal of used batteries should be carried out in accordance with the local (national or regional) regulations
- To prevent the battery from being damaged, do not drop the battery or allow it to hit solid objects or to be scratched by the objects.
- Do not let the battery come in contact with metal objects (including coins) to avoid short circuiting, discharging, excessive heat, or possible leakage.
- Do not attempt to disassemble the battery.
- Do not expose the battery to water. Always keep the battery contacts dry.
- Do not heat the battery or throw it into a fire to avoid a possible explosion.
- Do not store the battery in a hot environment or in direct sunlight.
- Only use the supplied battery.

- If the rechargeable Li-ion battery in this camera overheats during charging, stop charging immediately and wait until it cools down to resume charging.
- When the camera is stored for a long period of time, remove the battery and keep it in a dry place that is not accessible to the infants and children.
- In a colder environment, the performance of the battery could be noticeably reduced.
- When you install the battery, install it according to the positive and negative markings on the battery compartment. Never force it into the battery compartment.

### Safety notes for memory card

- Do not drop the memory card or allow it to hit solid objects to avoid damaging it.
- Do not attempt to disassemble or repair the memory card.
- Do not expose the memory card to water. Always keep it dry.
- Do not remove the memory card when the camera is turned on. Otherwise, the memory card could be damaged.

- Do not directly edit the data on the memory card. Copy the data to your PC before you edit them.
- When the camera is stored for a long period of time, be sure to download your photos and remove the memory card. Store it in a dry environment.
- Format the memory card using the camera before you use it or insert a new one.
- We suggest buying only well-known, name brand memory cards to ensure peak performance.
- Do not modify the name of the files or folders of the memory card using your PC. Modifying the file names may cause the files to not be recognized on the camera or a possible error may occur.
- A photo taken with the camera will be stored in the folder that is automatically generated on the SD card. Do not store photos that are not taken using this camera in these folders as the pictures cannot be recognized during the playback.
- When you insert a memory card, make sure the notch of the card matches the markings on the top of the card slot

### Other Safety Notes

- Do not disconnect the power or turn the camera off during the update process. Doing so may cause incorrect data to be written and the camera may not power on later.
- Do not hang the neck strap of the camera around the neck of a child.
- When using your camera on an airplane, observe the relevant rules specified by the airline.
- Due to the limitations of manufacturing technology, the LCD screen may have a few dead or bright pixels. These pixels do no effect the quality or performance of the camera, photos or video.
- Do not expose the LCD screen to water. In a humid environment, only wipe it with a soft and dry cleaning cloth.
- If the LCD screen is damaged and the liquid crystal comes into contact with your skin, wipe your skin with a dry cloth immediately and rinse it with clean water. If liquid crystal comes into contact with your eyes, wash them with clean water at least for 15 minutes and seek immediate medical attention. If you accidentally swallow liquid crystal, rinse your mouth immediately and seek medical attention.

# **CONTENTS**

BEFORE YOU START	1
SAFETY NOTES	2
CONTENTS	5
GETTING READY	9
Accessories Included	9
Install lens cap and neck strap	10
Part Names	11
Installing Battery and Memory Card	14
Charging Battery	16
Turning Camera On and Off	17
Symbol Description	17
Set your Language, Date/Time	18
Set your Language, Date/Time after the first power-on	18
Resetting your Language	18
Resetting Date/Time	19

MODE OVERVIEW	20
Display Setting	20
LCD Screen Display	21
Overview of the screen icons in photo shooting mode	21
Overview of the Screen Icons in Movie Mode	23
Overview of the Screen Icons in Playback Mode	24
Using the Mode Dial	25
Auto Mode	26
Auto Program Exposure	26
Shutter Priority	27
Aperture Priority	27
Manual Mode	28
Face Beautifier	28
Panorama Mode	29
Scene Mode	30

Auto Scene Mode	33
Black and White	34
Custom Settings	35
BASIC OPERATION	36
Using the Zoom Function	36
Focus Setting	37
Macro Mode	37
Self-Timer Setting	38
Flash Mode	39
White Balance Setting	40
Continuous Shot	41
EV Setting	42
Exposure Compensation	42
ISO	43
Shutter Adjustment	43
Aperture Adjustment	44
Using Quick Recording	44

i Button Function Menu	45
PLAYBACK	46
Viewing Photos and Videos	46
Thumbnail View	47
Using Zoom Playback (for still pictures only).	48
Slideshow	49
Continuous Capture Group Playback	49
Photos and Video Deletion	50
USING THE MENUS	51
Photo Setup Menu	51
Expo Metering (Exposure Metering)	51
Image Size	52
OIS	52
Cont. AF	53
HDR	53
Beauty	54

Scene54	Resize	64
Photo Shooting Setting Menu56	Color Effect	64
Quality56	Playback Setting Menu	65
AF-Assist Beam57	Protect	65
Digital Zoom57	Delete	66
Date Imprint57	DPOF (Digital Print Order Format)	67
Quick Review58	Trim	68
Custom Settings58	Setup Menu	69
Movie Menu59	Sound Settings	70
Expo Metering (Exposure Metering)59	Power Saver	70
Video Quality60	Language	70
OIS60	Zone	71
Movie Setting Menu61	Date/Time	71
Digital Zoom61	File / Software	71
Playback Menu62	Format Memory	71
HDR62	Copy to Card	72
Red-Eye Reduction63	File Numbering	72
Rotate63		

Reset	73
FW Version	73
CONNECTIONS	74
Connecting to a Computer.	74
Setting the USB Mode.	74
Transferring files to you	r computer74
Video System	75
Set Eye-Fi SD Card Connec	ction Mode76
Supported HDMI Connection	ns77
Connecting HDMI-Read	dy TV77
Connecting to a PictBridge	Compatible Printer. 78
Setting the USB Mode.	78
Connecting to your Prin	ter79
Using the PictBridge Menu.	80
Print (with Date)	80
Print (without Date)	81

Print Index	82
Print DPOF Images	83
Exit	83
ADDENDICEC	0.4
APPENDICES	84
Specifications	84
Prompts and Warning Messages	88
Troubleshooting	91

### **GETTING READY**

### Accessories Included

Your camera box should contain the camera model you purchased along with the following accessories. If anything is missing or appears to be damaged, please contact your retailer.



Rechargeable Li-ion battery



Neck strap



AC adapter





Service card



CD-ROM



USB cable



Warranty card




Quick start guide





Lens cap with strap


### Install lens cap and neck strap





### Part Names













1	AF Assist Beam/Timer Indicator	11	Playback Button	21	Shutter Button
2	Flash Lamp	12	AF Button/Arrow Button (Up)	22	Continuous Capture Button
3	Microphone	13	Flash Button/Arrow Button (Right)	23	Exposure Compensation Button
4	Lens	14	Delete Button/Self-Timer Button/Arrow Button (Down)	24	Power Switch
5	LCD Screen	15	Macro Button/Arrow Button (Left)	25	Mode Dial
6	Fast Video Recording Button	16	SET Button	26	Flash Button
7	Status Indicator	17	Strap Eyelet	27	Speaker
8	i Button	18	USB Port	28	Tripod Socket
9	Menu Button	19	HDMI Port	29	Battery Cover
10	Display Button	20	Zoom Lever		


### Installing Battery and Memory Card


1. Open the battery cover.






2. Insert the battery into the battery slot in the correct position as shown in the following diagram:






3. Insert the memory card into the memory card slot as shown in the diagram below:




The memory card (SD/SDHC) is optional and not included in all camera packaging. If you have to purchase a memory card, select one with storage capacity between 4GB and 32GB to ensure correct data storage.

To remove your memory card, open the battery cover, gently press the memory card to eject it and remove it carefully.

4. Close the battery cover.






### **Charging Battery**

Before charging the battery, ensure that the battery is inserted properly and the camera is off.


- Connect the camera and the power charger using the supplied USB cable. (The plug shape of the power charger may vary depending on the country or region. The actual item may vary from the drawing below).
- Insert the plug of the power charger into the wall outlet to charge the battery.



The charger is for indoor use only.

After the battery is stored for a long period of time, use the supplied power charger to charge the battery prior to use.

When the camera is turned off, you can also connect the camera to your PC using a USB cable to charge the battery.



Charging indicator:

Red: Charging

The indicator will go out once charging is finished, and the camera will be powered off automatically.

To have maximum battery life, charge the battery for at least 4 hours the first time.




Charging the battery should only be done with the camera in the "off" position.



Please charge the battery indoors between 0°C and 40°C

### Turning Camera On and Off

Slide the power switch to turn on/off the camera.



### Symbol Description

In the instructions below, the following symbols may be used throughout this manual on how to operate the camera. This is to facilitate better understanding.

[Button name] : When one button on the camera cannot be indicated by an icon,

the symbol [] is used to indicate

it.

 $\lceil$  Item properties  $\rfloor$  : The optional properties in the camera interface are indicated

by the symbol \( \cap \).

### Set your Language, Date/Time

# Set your Language, Date/Time after the first power-on

- 1. When you turn the camera on for the first time, the language selection screen appears.
- 2. Press the arrow buttons to select your desired language.
- After you press the (set) button to confirm the selection, the Date/Time settings screen appears.
- Press the left/right arrow button to select the Date/ Time to be adjusted: Time is displayed in YYYY. MM.DD HH:MM.
- Press the up/down arrow button to adjust the value for the selected Date/Time.
- 6. Press the set button to confirm the time settings and the snapshot screen appears.

#### Resetting your Language

After you set your language for the first time, follow the instructions below to reset your language.

1. Turn the camera on via the power switch.

- 2. Press the button, press the up/down arrow button to select , and press the str button to enter the menu.
- Press the up/down arrow button to select , and press the str button or right arrow button to enter the menu.
- 4. Press the up/down arrow button to select 
  「Language」 and press the [st] button or right arrow button to enter the menu.
- 5. Press the arrow buttons to select your desired language and press the set button to confirm.
- 6. Press the button and the snapshot screen appears.





#### Resetting Date/Time

After you set your Date/Time for the first time, follow the instructions below to reset date and time.

- 1. Turn the camera on via the power switch.
- 2. Press the button, press the up/down arrow button to select , and press the set button to enter the menu.
- Press the up/down arrow button to select , and press the sr button or right arrow button to enter the menu.
- 4. Press the up/down arrow button to select

  Date & Time and press the structure button or right arrow button to enter the menu.
- Press the left/right arrow button to select the Date/ Time to be adjusted: Time is displayed in YYYY. MM.DD HH:MM.

- Press the up/down arrow button to press the value for your selected block. After you finish your settings, press the (set) button to confirm.
- Press the button and the following snapshot screen appears.





### **MODE OVERVIEW**

### **Display Setting**

Press the [058] button to display the settings: Classic, Full, Off.

Classic: Displays the camera parameters on screen



Full: Camera parameters with Grid and Histogram





Off: Does not display any additional icons on screen



### LCD Screen Display

# Overview of the screen icons in photo shooting mode





1 Shooting Mode Icons

Auto Mode + Face Beautifier

P Program AE Panorama Mode

Shutter priority SCN Scene Mode

A Aperture priority **CS** Custom Settings

Manual Mode

- 2 Macro Mode
- 3 Zoom Display (By turning the Zoom Lever)
- 4 SD Memory Card/Built-In Memory
- 5 Battery Status
- 6 White Balance (Adjustable only in **P S A M** Mode)
- 7 Color Effect (Adjustable only in **P s A M** Mode)
- 8 Number of remaining shots
- 9 Image Size
- 10 Video Quality
- 11 ISO Value (Adjustable only in P A M \* Mode)
- 12 Remaining Recording time

- 13 Exposure Compensation (EV value) (Adjustable only in P S A \*\* Mode)
- 14 Shutter Speed (Adjustable only in **S M** Mode)
- 15 Histogram
- 16 Aperture Value (Adjustable only in **A M** Mode)
- 17 Image stabilization
- 18 Focus Frame
- 19 Expo Metering
  - - AiAE
  - Spot
  - Center
- 20 AF Mode
  - Single-AF
  - [∞] Multi-AF
  - Object Tracking
- 21 Self-Timer



Self-timer Off



2 sec



10 sec




Smile

- 22 Flash Mode
- Flash Auto
- 5

Force Flash

- Slow Sync.
- Slow Sync. + Red-Eye
- Red-Eye Reduction
- 23 Continuous Shot
- Single
- Continuous Shot
- (FHS
- Cont. Shot- High Speed (VGA)
- Cont.Shot-Fast (4M)
- **6**
- Time-Lapse (30sec/1min/5min/10min)
- 24 Eye-Fi ON (with signal)
- 25 HDR (Adjustable only in p s A M Mode)

#### Overview of the Screen Icons in Movie Mode



- 1 Movie Mode Icons
- 2 Macro Mode
- 3 Self-Timer



Self-timer Off



10 sec

- 4 Zoom Display (by turning the Zoom Lever)
- 5 SD Memory Card/Built-In Memory
- 6 Battery Status

- 7 Color Effect
- 8 Video Quality
- 9 Remaining Recording time
- 10 Exposure Compensation (EV value)
- 11 Image stabilization
- 12 Focus Frame
- 13 Eye-Fi ON (with signal)
- 14 Expo Metering



AiAE



Spot Center

15 AF Mode




For optimal video shooting, it is recommended that an SDHC memory card be used. If you shoot video using only the camera's internal memory, the end results may have image jitter, noise and vastly shorter recording times.



Optical Zoom and Digital Zoom can be adjusted. Digital Zoom can be adjusted to 4X (144X in total).

# Overview of the Screen Icons in Playback Mode



- 1 DPOF File
- 2 File Protection
- 3 Memory space (indicating the current number of photos and total number of photos)
- 4 SD Memory Card/Built-in Memory
- 5 Battery Status
- 6 Zoom Magnification Area
- 7 Image Zoom Ratios
- 8 Image Zone
- 9 Shooting Date
- 10 Continuous Capture Group Playback
- 11 Eye-Fi ON (with signal)
- 12 Red-Eye Reduction
- 13 HDR
- 14 Date Folder

### Using the Mode Dial

This Camera provides a convenient mode dial that allows you to manually switch between different modes with ease. The available modes are listed below:

Mode Name	Icon	Description	
Auto Mode	ā	In this mode, the optimal conditions for taking pictures will be set based on the subject and environment. It is the most commonly used mode for taking pictures.	
Program AE	Program AE P Setting allows you to choose the EV value and the camera will select both the shutte speed and aperture automatically.		
Shutter priority	S	Setting allows you to choose a specific shutter speed so the camera will adjust the aperture automatically to ensure correct exposure.	
Aperture priority	A	Allows you to choose a specific aperture and the camera will automatically adjust the shutter speed to match it.	
Manual Mode	М	Many of the camera settings can be configured manually in this mode.	
Face Beauti- fier	+2)	This mode automatically enhances facial features with skin softening touches and eye brightening capabilities.	
Panorama Mode	П	Switch to this mode to take a series of pictures which will be stitched into a panoramic picture by the camera.	
Scene Mode	SCN	Choose from 25 different pre-set scene types and effects for your photos.	
Movie Mode	è	Record videos.	
Custom Set- tings	cs	The user can store the frequently used shooting modes and parameters and switch to this mode for quick adjustment.	

### Auto Mode

Auto Mode is the easiest mode to take photos. While operating in this mode, the camera automatically optimizes numerous camera settings to adjust your photos and videos for the best possible results.

#### Follow these steps:

- 1. Use the power switch to turn the camera on.
- 2. Switch the Mode Dial to Auto Mode ( ).
- Compose your picture in the LCD screen and press the Shutter button halfway down to focus on the subject.
- 4. The LCD screen will show a green focus frame when the subject is in focus.
- Fully press the shutter button down to take pictures.

### Program AE P

When **P** (Program AE) mode is selected, you can adjust the EV value and ISO value.

 Turn the mode Dial to P and press the D button to configure settings.



- Press the left/right arrow button to select an adjustment item.
- 3. Press the up/down button to adjust the parameters.
- Press the (ser) button to engage the settings and enter the shooting screen.

### Shutter Priority S

When **5** (Shutter Priority) is selected, you can adjust the shutter speed and EV value. The camera automatically sets the aperture value based on the shutter speed value to get the most appropriate exposure value.

1. Turn the mode Dial to **S** and press the button to configure settings.



- 2. Press the left/right arrow button to select an adjustment item.
- 3. Press the up/down button to adjust the parameters.
- 4 Press the (str) button to confirm the settings and enter the shooting screen.

### Aperture Priority A

When selecting **A** (Aperture Priority) mode, you can adjust the aperture size / EV value and ISO value. Selecting a large aperture opening will emphasize the point of focus and show a blurry background and foreground. A small aperture opening will keep both the background and main object in clear focus.

1. Set the mode Dial to **A** and press the **B** button to enter the Aperture Priority setting's menu.



- 2. Press the left/right button to select EV/aperture.
- Press the Up/Down button to select the parameter adjustment.
- 4 Press the (set) button to confirm the settings and enter the shooting screen.

### Manual Mode M

When selecting manual ( **M** ) mode, you can set the aperture / shutter speed manually and ISO value.

 Turn the Mode Dial to M and press the Dutton to configure settings.



- 2. Press the left/right arrow button to select an adjustment setting.
- Press the up/down button to adjust the parameters.
- Press the (str) button to confirm the settings and enter the shooting screen.

#### Face Beautifier \*\*

In Portrait Mode, the camera is set to automatically adjust camera exposure for realistic portrayal of skin tones.

- 1. Turn the Mode Dial to select Face Beautifier Mode ( \*\*) ).
- Press the left/right arrow button to select Face Beautifier and press the (set) button to confirm and return to photo shooting mode.



Beautifier Mode has 3 effects:

- Effect 1: Skin Soften
- 🎇 Effect 2: Skin Soften + Eye Brightening
- Kg Effect 3:Skin Soften + Eye Brightening + Eye Enlargement

### Panorama Mode

With Panorama Mode, you can take a series of pictures which will be stitched automatically into a ultra-wide panoramic picture by the camera.

#### Follow the steps below:

- Turn the Mode Dial to Panorama Mode ( ) .
- 2. Press the arrow buttons to select a shooting direction. (The right direction is used as default if you do not make any choice) 2 seconds later, the camera is ready to take pictures. You can also press the structure button to be ready to take pictures.
- Compose your shot on the LCD screen and half press the shutter button to focus on the subject. After focusing, fully press the shutter button down to take the first picture. At this time, the process dialog of panorama mode stitching appears on the screen.

direction. When the range of movement or rotation meets the internal settings of the camera, the progress dialog along the indication arrow partially turns red. When it completely turns red, panorama mode shooting is finished.

5. The camera automatically stitches the pictures

4. Move or rotate the camera according to the set

The camera automatically stitches the pictures taken into a panoramic picture. After stitching, you can preview it for 1 second.







During shooting, the flash, self-timer, macro modes and exposure compensation are not available. Focus adjustment is also not available at this time.



During panorama mode shooting, press the ser button to interrupt shooting and save the current pictures taken. Press the down arrow button ( ) to cancel shooting and not to save the previously taken pictures.



During panorama mode shooting, when the moving direction of the camera is wrong or the angle deviates from the internal settings, the LCD shows a warning message 「Improper alignment. Please try again.」 and the current pictures taken are saved.

### Scene Mode scn

You can select an appropriate mode from the 25 scene modes according to the type of environment you are shooting. The camera then configures the most appropriate settings automatically.

Turn the Mode Dial to the Scene Mode to enter the Scene Mode menu. What the LCD screen displays is shown in the screen shot below:



Press the arrow buttons to select a scene, and press the (set) button to confirm.

Scene	Description
ASM Auto Scene	Identifies the scene automatically; Person, Backlighting, Landscape, Macro, Night Scene, Night Scene Person, Auto.
<u> </u>	For landscapes and outdoor shots. Vivid reproduction of green and blue.
Sport Sport	For fast-moving subjects. Capture sharp, action shots with minimal blur. This mode is not recommended for shooting indoors.
A Beach	For taking pictures in areas with strong sunlight.
Sunset	For sunsets. Capture subjects in strong sunlight.
Fireworks	For fireworks at night. Slower shutter speed is adjusted for brilliant images. The use of a tripod is recommended.
Night Landscape	For night scenes. The use of tripod is recommended.
Sketch	For taking photos with pencil sketch effect.
Snow	For snow scenes. Reproduce natural, clear white scenes.
Children	Turns off flash automatically. Avoids disturbing subject, suitable for taking photos of children.
ID	For shooting ID size photos. (It is recommended to print using 6-inch 4R (6X4) photographic paper).
<b>Glass</b>	For objects behind transparent glass.
■ Photo Frame	For adding interesting frame effects to the photo.

Scene	Description
Panning Shot	Suitable for capturing fast moving objects to have a clear subject with a blurred background.
Portrait	Most suitable for capturing people with focus on their face.
Fish Eye	For interesting fish eye effect.
Party	Suitable for taking indoor party pictures, even under the complicated lighting conditions.
	For indoor settings. Reduce blur and improve color accuracy.
Leaf	For plants. Capture brilliant shots of greenery and blossoms.
Museum	For museums or flash-free areas. Retain color and reduce blur.
Night Portrait	For portraits against night scenery.
Pet Mode-Dog	Quickly identifies a dog, capturing quick or unexpected movements.
Pet Mode-Cat	Quickly identifies a cat, capturing quick or unexpected movements.
Black and White	Take fun photos in different colors.
Multi Exposure	Take several photos continuously.

#### Auto Scene Mode (ASCN)

In "ASCN" scene mode, the camera can detect different environments intelligently and automatically select the best scene and photo settings for you.

#### To use "ASCN":

- 1. Turn the Mode Dial to "SCN" and select "ASCN" mode.
- 2. Hold the camera steadily and aim at the subject. The optimum scene mode will be selected automatically.
- 3. Press the shutter button half-way down to focus.
- 4. Press the shutter button all the way down to take pictures.



Mode Name	Description
Landscape Mode	For landscapes, ASCN will automatically adjust the exposure and reproduce vivid green and blue colors.
Portrait Mode	Most suitable for capturing people with focus on their faces.
Night Portrait	When you take portraits at night, or in low light conditions, ASCN will automatically adjust the exposure for people and night scenes.
Backlit Portrait	When the sun or any other light source is behind you, ASCN will automatically adjust the foreground exposure to produce the best pictures possible.
Night Landscape Mode	For night scenes, ASCN will automatically increase the ISO value to compensate for low light.
Macro Mode	To produce more detailed close-ups, ASCN will automatically engage the camera's Macro Mode and automatically focus the lens.
Auto Mode	The camera will automatically adjusts the exposure and focus to ensure the best possible pictures.

#### **Black and White**

In the of Black and White Mode, you can take pictures with different black and white effects.

To use " ":

- 1. Turn the Mode Dial to "SCN" and select "

  "" mode, and press the (set) button to confirm, press i button to enter for setting.
- 2. Press the left/right arrow button to select the Black and White option.



3. Press the (SET) button to show the photo shooting screen.

In the Black and White Mode, the black and white effect has the following 8 options:



Black and White



B&W + HDR



Sepia



Color Separation (red)



Color Separation (yellow)



Color Separation (blue)



Color Separation (green)



Salon

### Custom Settings CS

The user can store the frequently used shooting modes and parameters and switch to this mode for quick adjustment.

Follow the steps below:

- 1. Select any mode or scene mode to be stored.
- 2. Set your desired parameters in the current mode.
- 3. Press the button, press the up/down arrow button to select , and press the set button to enter the menu.
- Press up/down arrow button to select , and press the str button or right arrow button to enter the menu.
- 5. Press the down arrow button select Custom Settings and press the set button or the right arrow button to enter the menu.



6. Select \( \text{Yes} \) to save or \( \text{No} \) to cancel.




- Turn the mode dial to switch to the custom settings ( CS ).
- 8. The photo settings you stored the last time are invoked.
- The factory default settings are Program AE (  ${\bf p}$  ) and other parameters.
- Custom Settings only keep the photo shooting mode and parameters you set the last time you used the camera in this mode.

# **BASIC OPERATION**

## Using the Zoom Function

Your camera is equipped with two types of zoom functions: Optical Zoom and Digital Zoom. Toggle the Zoom Lever of the camera to zoom in or out of the subject while taking pictures.





-Zoom Indicator

When the Optical Zoom reaches the threshold as Digital Zoom, release and turn the Zoom Lever to T to switch between the Optical zoom and Digital zoom.

## **Focus Setting**

In different photo shooting modes, you can select different focus methods.

 Press the up arrow button ( AF ) to display the settings screen.



- 2. Press the left/right to select the following 3 modes:
  - Single-AF: The focus frame appears on the center of the LCD screen to focus on the subject.
  - Multi-AF: The camera automatically focuses the subject in a wide area to find the focus point.
  - Object Tracking: Smart tracking of the object in motion under the focusing shooting.
- Press the set button to confirm the settings and exit the menu.
- Once enabled, Object Tracking will only work when lens is focused on the object.

## Macro Mode

The Macro Setting is ideal for shooting small objects or close-up photos. This mode allows you to focus on subjects very close to the camera.

 Press the left arrow button ( ) to enter the Marco Menu.



- 2. Press the left/right to select the following 2 modes:
  - Macro Off
     Select this option to disable Macro.
  - Macro On Select this to focus on subjects 5cm from the lens.
- Press the (ser) button to confirm the settings and exit the menu.


## Self-Timer Setting

Using this function can take photos at regular time. The camera can be set to shoot after 2 seconds, 10 seconds since pressing the shutter or shoot after smile

Press the down arrow button ( \*\* \*\odot\*) to enter the self-timer menu.



- 2. Press left/right to select the following 4 modes:
  - Self-Timer Off
    Disables the Self-Timer.
  - Self-Timer 2 sec
    A single picture is shot 2 seconds after
    the Shutter Button is pressed.




Self-Timer 10 sec
A single picture is shot 10 seconds after
the Shutter Button is pressed.

- Self-Timer Smile
  Press the Shutter Button and a picture
  will be taken immediately after a smile is
  detected.
- 3. Press the set button to confirm the settings and exit the menu.

## Flash Mode

The flash is mainly for supplementing light for the scene. The flash is usually used in shooting against the light to highlight the object shot through lightening the object while darkening the background; it is also suitable for metering and shooting in darker scenes through exposure.

Press the co Flash pop-up Button to pop up the flash.



2. Press the right arrow button ( \$\frac{1}{2}\) ) to enter the Flash Settings Menu.



- 3. Press the left/right to select the following 5 modes:
  - Flash Auto
     Camera flash goes off automatically based on existing light conditions.
  - Force Flash
    The flash will engage with each shot even
    if there is enough available light to take
    the photo without flash.
  - Slow Sync.
    This allows for night scenery photos that include people in the foreground. The use of a tripod is recommended when shooting with this setting.
  - Slow Sync. + Red-Eye
    Use this mode for slow synchro shots with
    red-eye reduction.
  - Red-Eye Reduction
    The camera emits a brief pre-flash before
    the picture is taken to reduce red-eye
    effects.
- 4. Press the (SET) button to confirm the settings and exit the option.

## White Balance Setting

The White Balance Setting allows you to adjust the color temperature for different lighting sources to ensure the most accurate color reproduction.

Follow the steps below to set white balance of the camera:

1. Press (set) button to enter White Balance Menu.



2. Press the left/right to select the following 8 modes:

- AWB AWB
- Daylight
- Cloudy
- Fluorescent
- High Fluorescent CWF
- Incandescent
- Manual WB (Fully press the shutter button to detect the white balance value)
- Color Temp. (1900K~10000K)
  Press direction buttons Up / Down to
  "Adjust the K value"; Press the direction
  button Left to exit the K value.
- 3. Press the (set) button to confirm the settings and exit the menu.

## **Continuous Shot**

Follow the steps below to configure the Continuous Shot Settings:

1. Press the to enter the Continuous Shot Menu.



- 2. Press the left/right to select the following 5 modes:
  - Single
     Capture a single shot only.
  - Continuous Shot
    Shoot at the rate of 5 pictures per second
    with the maximum pixel setting. (Slow
    down starting from No. 8)

- Cont.Shot-High Speed (VGA)
  Continuously capture using VGA pixel,
  up to 60pix/sec with a maximum of 120
  images.
- Cont.Shot-Fast (4M)
  Continuously capture 4MP images, up to 30pix/sec with a maximum of 60 images.
- Time-Lapse
  Take pictures based on the preset interval
  (30sec/1min/5min/10min).
- 3. Press the set button to confirm the settings and exit the menu.
- 4. Press the Shutter button to start continuous shooting.
- The flash is disabled in this mode in order to achieve quick succession of shots.

## **EV** Setting

The EV function menu of the camera includes functions, such as EV adjustment, ISO, shutter, aperture, etc. Using the appropriate function settings can improve your pictures.

To select the best setting for optimum photos, follow these steps:

- 1. Press the (2) button to display the settings screen.
- Press the left/right arrow button to select the setting options.



- 3. Press the up/down button to adjust the option values.
- Press st button to complete the setting and enter shooting mode.

## **Exposure Compensation**

Set up to adjust the picture brightness. In the case of a very high contrast between the photographed object and the background, the brightness of the picture can be appropriately adjusted. (Adjustable only in **P S A \*\* \*\* \*\* Mode**)



The adjustable range of exposure value is from EV -3.0 to EV+3.0.

#### ISO

The ISO function allows you to set the sensitivity of the camera's light sensor based on the brightness of the scene. To improve the camera's sensor performance in darker environments, a higher ISO value is required. A lower ISO value is needed when shooting in brighter conditions.

Pictures taken at higher ISO settings will generally have more noise than those taken at lower ISO settings. (Adjustable only in **P A M \*®** Mode)



The camera's ISO settings include: automatic, 100, 200, 400, 800, 1600 and 3200.

### **Shutter Adjustment**

For shutter speed, the camera may automatically set the aperture value corresponding to the manually set shutter speed so as to obtain a most suitable exposure value. The movement of object may be shown by adjusting the shutter speed. High shutter value can make you clearly capture the movement of fast moving object while low shutter value can allow you to take a picture for fact moving object with a strong sense of movement. (Adjustable only in **S M** Mode)



## **Aperture Adjustment**

You can adjust the aperture size value. Selecting a large aperture opening will emphasize the point of focus and show a blurry background and foreground. A small aperture opening will keep both the background and main object in clear focus. (Adjustable only in **A M** Mode)



## **Using Quick Recording**

In shooting mode, press the Recording shortcut button ( ) to begin recording video.



After finishing, press the Recording short cut button or the Shutter Button to stop and store the video. The camera will return to shooting mode automatically.

## i Button Function Menu

## Mode: P S A M 🖦

The Image Color Setting allows you to select different color effects.

- Press the j button to select the Image Color Setting Menu.
- 2. Press the left/right arrow button to select the Image Color Setting options.



There are 5 Image Color options in photo shooting mode  ${\bf P}$  S  ${\bf A}$   ${\bf M}$ :

- 🚳 Normal
- 🗁 Vignetting

- 🔠
- Salon
- K

Dreamy

There are 4 Image Color options in Movie Mode **•**:

- .
- Normal
- · 🚳
- Vivid
- · 🚳
- Sepia
- Black and White


# **PLAYBACK**

## Viewing Photos and Videos

To view the captured photos and video clips on the LCD screen:

- 1. After pressing the Dutton, the last photo or video clip taken will be displayed on the LCD screen.
- Use the Left/Right navigation buttons to scroll through the photos or video clips stored in the internal memory or on the SD memory card.
- 3. To play a selected video clip, press the (set) button to enter the Movie Playback Mode.

An operation guide appears on the screen when playing back a video. Press the appropriatbuttons to enable the corresponding functions.



1	Increase Volume
2	Pause
3	Fast Forward
4	Decrease Volume
5	Rewind

#### Pause mode



6	Back to the beginning of the video
7	Play
8	Play video forward
9	Cancel playback
10	Play video backward


## Thumbnail View

When in Playback Mode, rotate the Zoom Lever counter clockwise to the **w Q** position to display thumbnail images of the photos and videos on the screen.



T Zoom In

- 1. Slide the Zoom Lever to switch between 3x3 and 4x4 thumbnails
- When a 3x3 or 4x4 thumbnail is displayed, press the arrow buttons to select a picture or video clip to view.





3 Press i button to select continuous shooting playback and date playback.





- 4. Press the arrow buttons to select a picture or video clip to view and press the (st) button to restore it to the original size.
- The Date Folder is displayed in date order based on camera's Date/Time Settings.
- If the indicator appears on the LCD, then a movie file is currently being displayed.
- Press the (st) button to restore a preview icon to its original image size.

# Using Zoom Playback (for still pictures only)

When playing back photos, you can also use the Zoom Slider to zoom in on the photos 2 to 8 times.

- 1. Press the Dutton to switch to Playback Mode.
- Press the left/right button to select a picture to be zoomed in.
- 3. Rotate the Zoom Lever clockwise to ( ♠ ↑ ) to zoom in.
- The bottom right corner of the screen will display the number of times and area of the photo zooming operation.



- 5. Press the arrow buttons to navigate and select a part of the image to be zoomed in.
- Press the set button to return the image to its original scale.



Movie images cannot be magnified.

### Slideshow

This setting allows you to view all the stored images as a slideshow.

- 1. Press 🗖 button to enter playback screen.
- 2. Press (SET) button to enter slide option.
- Press the left/right button to select slideshow playing or 「Cancel」 to return to the playback screen.



4. Press the (SET) button to confirm the setting.



The continuous capture group playback may be displayed by slideshow.

## Continuous Capture Group Playback

Ultra-high speed (VGA) and high speed (4M) can make continuous capture for group image playback.

- 1. Press button to enter playback screen.
- Press the left/right arrow button to select Cont. Group.
- 3. Press (SET) to start playback.



## Photos and Video Deletion


In playback mode, press the down arrow button ( 🛊 🖒 ) to delete your photos and videos.

To delete photos or videos:

- 1. Press the **b** button to switch to playback mode.
- Press the left/right arrow button to select the photos and videos to be deleted.
- Press the down arrow button ( ) and the deletion screen is displayed.



- Press the up/down arrow button to select
   「Delete One」 or 「Exit」 and press the (set) button to confirm.
- Prased photos/video clips cannot be recovered.



# **USING THE MENUS**

## Photo Setup Menu

## Mode: P S A M + SCN

- 1. In Photo Shooting Mode, press the button to enter the Photo Shooting Menu.
- Press the up/down arrow button to select the Photo Shooting Menu to be set.
- Press the left/right arrow button to select the Photo Shooting Menu to be set and press the set button to confirm.



Refer to the following pages for more details about each setting.

## **Expo Metering (Exposure Metering)**

Use this setting to select the "target" size of the camera's field of view to be metered.



#### There are 3 options:

- AiAE (Artificial Intelligence AE) targets the camera's entire field of view.
- Spot metering targets a small area in the center of the camera's field of view.
- Center metering targets a slightly larger area in the center of the cameras field of view.



AIAE (Artificial Intelligence AE): Automatically selects the central and peripheral metering, to calculate the reasonable value of metering by weighting.

## **Image Size**

The size setting refers to the image resolution in pixels. A higher image resolution allows you to print that image in larger sizes without degrading the image quality.





The bigger the number of recorded pixels is, the better the image quality becomes. As the number of recorded pixels lessen, you will be able to record more images on a memory card.

#### OIS

This mode can help reduce photo blur caused by unintentional hand shake, low light or slow shutter speed.





Use Stabilization Mode in dark environments or when using a slower shutter speed.



Shooting in a windy or unstable environment (such as a moving vehicle) may cause blurred images.

#### Cont. AF

Enable the continuous AF to be able to continuously focus automatically when taking pictures.



#### There are 2 options:

- Off
- On

#### **HDR**

Use this setting to control wide dynamic image range when taking static pictures. Photos with extreme contrast of bright and dark areas will still maintain distinguishable detail and depth. (Use of tripod is recommended)



There are 2 options:

- Off
- On



In the scenario with high light contrast (too dark or too light), this function can be used to shoot satisfactory photos.

## Beauty

Set the effect of the beauty mode.



#### Beautifier Mode has 3 effects:

- K Effect 1: Skin Soften
- 🗞 Effect 2: Skin Soften + Eye Brightening
- K Effect 3: Skin Soften + Eye Brightening + Eye Enlargement

#### Scene

Select the scene mode under the SCN mode.



• Shooting menu in the shooting mode (O: Optional X: Not optional)

Options	Shooting Modes						
	Ď	P	S	A	М	+\$)	SCN
	0	0	0	0	0	0	o
16M	0	0	0	0	0	0	0
<b></b>	0	0	0	0	0	0	x
-1057 -1057	О	O	О	О	0	0	х
HDR	0	0	0	0	0	х	х
<b>8</b> € <sub>®</sub>	x	x	x	x	x	0	х
ASEN	x	х	х	x	x	х	0

## Photo Shooting Setting Menu

Mode: 

P S A M → SCN

1. Press the button in Photo Shooting Mode and press the up/down button to select



- 2. Press the (SET) button to enter the menu.
- Press up/down arrow button to select , and press the st button or right arrow button to enter the menu.
- 4. Press the up/down arrow button to select the item to be set and press the (sr) button or right arrow button to enter the menu.
- 5. Press the up/down arrow buttons to select an option and press the set button to confirm.

### Quality

The Quality Setting can be used to adjust the image compression ratio.



There are three options for picture quality:

- Best (16M Average File Size: 3.5MB)
- Fine (16M Average File Size: 1.5MB)
- Normal ( 16M Average File Size: 2.5MB)

#### **AF-Assist Beam**

In a darker environment, AF Assist Beam can be turned on for better focus.



## **Digital Zoom**

Turn on or off the digital zoom.



## **Date Imprint**

Include a Date/Time stamp on the photo image.





- Off
- Date
- Date / Time

#### **Quick Review**

This option allows quick review of the photos immediately after they are taken. Each photo is displayed on the LCD screen based on the selected time.




#### There are 4 options:

- Off
- 1 sec
- 2 sec
- 3 sec

### **Custom Settings**

Custom Settings stores the current photo shooting mode and its parameters. The stored mode and parameters are directly invoked in Custom Settings mode



#### There are 2 options:

- No
- Yes

### Movie Menu

## Mode:

1. Turn the mode dial, select the mode and press the button to enter the Movie Menu.



- Press the up/down arrow button to select the Movie Menu to be set.
- 3. Press the left/right arrow button to select the Movie Menu to be set and press the str button to confirm

## **Expo Metering (Exposure Metering)**

Use this setting to select the "target" size of the camera's field of view to be metered.



#### There are 3 options:

- AiAE (Artificial Intelligence AE) targets the camera's entire field of view.
- Spot metering targets a small area in the center of the camera's field of view.
- Center metering targets a slightly larger area in the center of the cameras field of view



AIAE (Artificial Intelligence AE): Automatically selects the central and peripheral metering, to calculate the reasonable value of metering by weighting.

## **Video Quality**

Set the image resolution used during video recording.



The speed requirements for reading and writing high image pixel images to SD card are as follows:

No.	Image Pixel	Frame	Recom- mendation	Recording time (4GB) About
1	1920x1080 *	30	Class 6	30 minutes
2	1280x720 *	60	Class 6	30 minutes
3	1280x720 *	30	Class 4	35 minutes
4	640x480	30	Class 4	50 minutes
5	320x240	30	Class 4	80 minutes
6	640x480	120	Class 6	50 minutes



<sup>\*</sup> The longest recording time is 29 minutes at one time.



When recording in higher pixel resolutions for extended periods of time, this can cause the camera to generate heat. This is not a camera malfunction.



When the video format is set as 640x480 (120fps), shooting time is 30 seconds, playback time is 2 minutes.

#### OIS

This mode can help reduce photo blur caused by hand shake, low light and slow shutter speed.





Use Stabilization Mode in dark environments or when using a slower shutter speed.



Shooting in a windy or unstable environment (such as a moving vehicle) may cause blurred images.

## Movie Setting Menu

### Mode: To

- Turn the Mode Dial and select to enter the video recording screen.
- 2. Press the button, press the up/down arrow button to select , and press the str button to enter the menu.



- Press up/down arrow button to select , and press the str button or right arrow button to enter the menu.
- 4. Select the items to be set and press the (ser) button or the right arrow button to enter the menu.
- Press the up/down arrow buttons to select an option and press the set button to confirm.

### **Digital Zoom**

Turn on or off the digital zoom.



## Playback Menu

## Mode:

- 1. Press the button to display the playback screen and press button to enter the menu.
- 2. Press the up/down arrow button to select the playback to be set and press (set) button to enter.
- 3. Press the left/right arrow buttons to select an option and press the (SET) button to confirm.



Refer to the following pages for more details about each setting.

#### **HDR**

With the HDR function, pictures that are overexposed may be corrected to optimize the highlights and lowlights captured to more accurately represent the actual scene.

- In Playback Mode, press the left /right arrow button to select the photos to be edited.
- Press the button, select the settings, and press the button to display the settings screen.
- Press the left/right button to select whether HDR is used.



 After using the HDR function, the image will be saved as a new file and the original file is still stored in the memory.

## **Red-Eye Reduction**

- 1. In Playback Mode, press the left /right arrow button to select the photos to be edited.
- Press the button, select the settings, and press the setting button to display the settings screen.




: Red-Eye Reduction

Skin Soften

Eye Brightening

4. Press the (SET) button to confirm the setting.



#### Rotate

You can use this setting to change the orientation of the picture.

- In Playback Mode, press the left /right arrow button to select the photos to be edited.
- Press the button, select the settings, and press the settings button to display the settings screen.
- Press the left/right button to select the rotation direction or 「Cancel」 to return to the playback Screen.



C: Turn Right

🕽 : Turn Left

X : Cancel

4. Press the (SET) button to confirm the setting.

Videos and panoramic pictures cannot be rotated.

The rotated picture file will replace the original photo.

#### Resize

This setting allows you to resize a picture to a particular resolution and saves it as a new picture.

- In Playback Mode, press the left /right arrow button to select the photos to be edited.
- 2. Press the button, select the settings and press the setting button to display the settings screen.
- Press the left/right arrow button to select 「1024X768」 or 「640X480」 or select 「Cancel」 to return to the playback Screen.



Press the (set) button to confirm the setting.

#### **Color Effect**

This setting allows you to change the picture color effect. The file is saved as a new photo and stored in memory together with the original photo.

- 1. In Playback Mode, press the left /right arrow button to select the photos to be edited.
- 2. Press the button, select the settings, and press the st button to display the settings screen.
- Press the left/right button to select the corresponding menu or 「Cancel」 to return to the playback Screen.




4. Press the (SET) button to confirm the setting.

💢 : Cancel	🔠 : Grainy
( : Vivid	: Vignetting
🚳 : Sepia	🛅 : Salon
🚳 : Black and White	🔄 : Dreamy

## Playback Setting Menu

## Mode: D

- Press the button to show the playback screen, press the button, and press the up/down button to select
- 2. Press the (SET) button to enter the menu.



- Press up/down arrow button to select , and press the str button or right arrow button to enter the menu.
- 4. Press the up/down arrow button to select the item to be set and press the st button or right arrow button to enter the menu.

 Press the up/down arrow buttons to select an option and press the (SET) button to confirm.

Refer to the following pages for more details about each setting.

#### **Protect**

To prevent any pictures or videos from being accidentally erased, use this setting to lock one or all of the files.



To lock or unlock the photo and video files:

1. Press the up/down arrow button to select

Protect \_ and press the str button or right arrow button to enter the sub-menu.

2. Press the up/down arrow button to select the sub-menu and press the sub-menu arrow button to show the settings screen.

There are 5 sub menus available:

One: Lock the selected photo or

video if they are unprotected; unlock the selected photo or video if they are protected.

• Date Folder: Protect all photos in the Date

Folder.

Cont. Group: Protect all photos in the Cont.

Photo Folder.

All: Lock all photos or videos.

Reset: Cancel all locked photos or

videos.

 Press the up/down arrow buttons to select an option and press the set button to confirm.

#### **Delete**

You can delete one or all photo/video files.



To delete photo or video files:

- Press the up/down arrow button to select
   Delete and press the strong button or right arrow button to enter the submenu.
- Press the up/down arrow button to select the submenu and press the st button or right arrow button to show the settings screen.

There are 4 sub menus available:

One: Delete one photo or video.

• Date Folder: Delete all photos in the Date


Folder.

• Cont. Group: Delete all photos in the Cont.

Photo Folder.

• All: Delete all photos or videos.

3. Press the up/down arrow buttons to select an option and press the (set) button to confirm.



Deleting files will cause DPOF settings to be reset.

When one photo in the Cont. Photo and Date Folders is protected, it will be kept but any other photos will be deleted.

### **DPOF (Digital Print Order Format)**

The DPOF feature allows you to compile and select a group of pictures that you would like to print and will save your selection on the memory card so that you can use the SD memory card to print without having to individually specify the photos you want to print.





The printer that supports DPOF is needed for printing.

#### Trim

The Trim Setting allows you to crop photos and save them as new pictures.

- Press the up/down arrow button to select 「Trim」 and press the st button or right arrow button to enter the menu.
- Select \( \text{Yes} \) to confirm trim. Select a part to be trimmed using the Zoom Lever and arrow buttons to trim a photo.



- 3. Press the (st) button and the 「Save change?」 prompt appears. Select 「✓」 to change and save the picture. Select 「✓」 to cancel changes and return to the trim prompt screen.
- The image cannot be clipped/trimmed again once it has been clipped to 640X480.

## Setup Menu

# Mode: 🔼 P S A M 🖏 🖂 SCN 🖦 🔼

- Press the button in any mode and press the up/down button to select .
- 2. Press the (set) button to enter the menu.
- Press up/down arrow button to select , and press the str button or right arrow button to enter the menu.



- 4. Press the up/down arrow button to select the item to be set and press the st button or right arrow button to enter the menu.
- 5. Press the up/down arrow buttons to select an option and press the (set) button to confirm.

Refer to the following pages for more details about each setting.

### **Sound Settings**

To change this setting:

- Select \( \subseteq \) Sound Settings \( \text{in the basic settings} \) menu. Press the \( \subseteq \) button or right arrow button to enter the menu.
- Press the left/right arrow button to select an option.



3. Press the (set) button to confirm.

#### **Power Saver**

This setting allows you to save power and get the maximum possible running time for your camera's batteries. Follow the steps below to turn the LCD screen and camera off automatically after a consecutive period of inactivity.

- Select 「Power Saver」 in the basic settings menu.
   Press the (sst) button or right arrow button to enter
   the menu.
- Press the up/down arrow button to select an option.



3. Press the (SET) button to confirm.

## Language

Refer to the "Reset your language" section on page 18.

#### Zone

The Zone setting is a useful function for your overseas trips. This feature enables you to display the local time on the LCD screen while you are abroad.

- Select \( \text{Vorld Time} \) in the basic settings menu.
   The World Time screen appears.
- Press the up/down to select the departure place ( ) and destination ( ) fields.
- Press the left/right arrow button to select a city located in the same time zone as that of the field.
   Press the (ser) button to confirm settings.



#### Date/Time

Refer to the "Reset Date/Time" section on page 19.

## File / Software

#### Format Memory

Please note: formatting enables you to delete all contents in the memory card and built-in memory, including protected photo and movie files.

To use this setting:

- Press the button, press the up/down arrow button to select and press the ser button to enter the menu
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- 3. Press the up/down arrow button to select Format and press the structure button or right arrow button to enter the menu.
- Press the up/down arrow buttons to select 「Yes」 or 「No」 and press the (set) button to confirm.



If you select \( \text{Yes} \) the camera formats its memory.



If there is no memory card in the camera, the built-in memory will be formatted; if there is a memory card, it will be formatted only.

#### Copy to Card

Use this setting to copy the files stored in the internal memory to an SD memory card.

- Press the button, press the up/down arrow button to select and press the str button to enter the menu.
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- Press the up/down arrow button to select Copy to Card and press the str button or right arrow button to enter the menu.
- Press the up/down arrow buttons to select \( \text{Yes} \) or \( \text{No} \) and press the \( \set{set} \) button to confirm.





If there is no card available in the camera, this function will not be displayed.

#### File Numbering

After you take a picture or video clip, the camera will save it with a sequential number. You can use this to reset the file numbering to 1.

- Press the button, press the up/down arrow button to select and press the str button to enter the menu.
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- Press the up/down arrow button to select File Numbering and press the st button or right arrow button to enter the menu.
- Press the up/down arrow buttons to select \[ Yes \]
  or \[ No \] and press the \( (set ) \) button to confirm.



#### Reset

Use this setting to restore the camera to its original default settings.

- Press the button, press the up/down arrow button to select and press the ser button to enter the menu.
- Press up/down arrow button to select and press the st button or right arrow button to enter the menu.
- 3. Press the up/down arrow button to select

  Reset and press the structure button or right arrow button to enter the menu.
- 4. Press the up/down arrow buttons to select 「Yes」 or 「No」 and press the (set) button to confirm.



#### **FW Version**

Use this setting to view the current camera firmware version.

- Press the button, press the up/down arrow button to select and press the st button to enter the menu.
- Press up/down arrow button to select and press the st button or right arrow button to enter the menu.
- Press the up/down arrow button to select FW
   Version and press the st button or right arrow
   button to enter the menu.



 When there is a new firmware version in the SD card, select <sup>¬</sup>Yes ₁ to update.

# CONNECTIONS

## Connecting to a Computer

You can use a USB cable to connect the camera and copy (transmit) photos to a computer, printer or other device.

#### **Setting the USB Mode**

The camera's USB port can be set to connect with either a computer or a printer. The following steps will allow you to ensure that the camera is correctly configured to connect with a PC.

- 1. Press the button, press the up/down arrow button to select and press the str button to enter the menu
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- 3. Press the up/down arrow button to select 「USB」 and press the str button or right arrow button to enter the menu.
- Press the up/down arrow buttons to select 「PC」 and press the (set) button to confirm.




#### Transferring files to your computer

The computer will automatically detect the camera as a removable drive. Double-click the My Computer icon on the desktop to locate the removable drive and to copy folders and files in the drive to a directory on your PC as you would copy any typical folder or file.

Follow the steps below to connect the camera to a computer.

- Make sure both the camera and computer are turned on
- Connect one end of the supplied USB cable to the USB/AV OUT port on your camera.

Connect the other end of the cable to an available USB port on your computer.




 After the transmission is complete, disconnect the USB cable according to the instructions specifying how to safely remove USB devices.

# Video System

Use this feature to switch the video system from either NTSC or PAL.

- Press the button, press the up/down arrow button to select and press the set button to enter the menu.
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- Press the up/down arrow button to select TV-System and press the st button or right arrow button to enter the menu.
- Press the up/down arrow buttons to select \[ \text{NTSC} \] or \[ \text{PAL} \] and press the \[ \text{str} \] button to confirm.



The video output signal can be switched to NTSC or PAL to accommodate different regional TV standards. The appropriate setting will vary between regions.

NTSC: USA, Canada, Taiwan, Japan, etc.

PAL: Europe, Asia (excluding Taiwan), Oceania, etc.

Note: The TV output will not display properly if an incorrect video system is selected.

# Set Eye-Fi SD Card Connection Mode

This camera supports wireless connection of an Eye-Fi SD Card. Upload the photos from the camera to the Internet using the following steps:

- Press the button, press the up/down arrow button to select and press the sr button to enter the menu.
- Press up/down arrow button to select and press the str button or right arrow button to enter the menu.
- Press the up/down arrow button to select 「Eye-Fi」
  and press the [st] button or right arrow button to
  enter the menu.
- Press the up/down arrow buttons to select 「On」 or 「Off」 and press the [set] button to confirm.






If the Eye-Fi card is not available in the camera, this feature is not displayed.

# Supported HDMI Connections

HDMI (High Definition Multimedia Interface), is a fully digital audio/video transmission interface, through which uncompressed audio and video signals are transmitted.

Direct transmission of digital video signals to your TV reduces conversion loss and improves image quality.



#### Connecting HDMI-Ready TV

- Use a High-Definition output terminal cable (not included) to connect your camera to an HDMI compliant TV.
- The camera will be automatically detected by the TV
- 3. After connecting via HDMI, the camera enters Playback Mode.



Make sure the camera and the TV are both turned on before connecting.



Refer to your TV instruction manual for information on what resolution sizes it will support.

The resolution and output formats that are not supported will be grayed out on the camera's LCD screen.

# Connecting to a PictBridge Compatible Printer



PictBridge technology allows printing of the photos saved in the memory card by the printer.

To find out if a printer is PictBridge compatible, simply look for the PictBridge

logo on the packaging or check the owner's manual for specifications. With the PictBridge function on your camera, you can print the captured photos directly to a PictBridge compatible printer using the supplied USB cable, without the need for a PC.

#### Setting the USB Mode

The camera's USB port can be set to connect with either a PC or a Printer, the following steps will ensure that the camera is correctly configured to connect with a Printer

- 1. Press the button, press the up/down arrow button to select earn and press the (set) button to enter the menu.
- 2. Press up/down arrow button to select w and press the (SET) button or right arrow button to enter the menu.

- 3. Press the up/down arrow button to select \( \Gamma USB \). and press the (SET) button or right arrow button to enter the menu
- 4. Press the up/down arrow buttons to select Printer | and press the (set) button to confirm.






After the camera is reset, it will switch to PC mode automatically from USB mode.




See "PictBridge" section on page 80.

#### **Connecting to your Printer**

- Make sure both the camera and printer are turned on.
- Connect one end of the supplied USB cable to the USB port on your camera.
- Connect the other end of the cable to the USB port on the printer.



If the camera is not connected to a PictBridge compatible printer, the following error message will appear on the LCD screen.






The error message above will also appear if the USB mode is set incorrectly, in which case you should disconnect the USB cable, check the USB mode settings, ensure that the Printer is turned on, and then try connecting the USB cable again.

# Using the PictBridge Menu

After setting the USB mode to Printer, the PictBridge Menu will appear.



Press the up/down arrow button to select a menu item and press the str button or right arrow button to enter the item.

Refer to the following sections for more detailed information on each setting.

#### Print (with Date)

If you have set the date and time on your camera, the date and time will be recorded and saved with each photo you take.

 In the PictBridge menu, select 「Print (with Date)」 and the screen as shown below appears.



2. Press the left/right arrow button to select a photo to be printed.

- Press the up/down arrow button to select the number of copies for the currently displayed photo.
- Press the (ser) button and the following screen will appear.



Select \( \textsup \text{es} \) and press the \( \begin{align\*} \setminus \text{er} \) button to confirm; select \( \text{Cancel} \) to cancel printing.

#### Print (without Date)

Use this setting to print the photos without dates on them.

In the PictBridge menu, select \( \text{Print} \) (without Date) \( \text{ and the screen as shown below appears.} \)



- Press the left/right arrow button to select a photo to be printed.
- Press the up/down arrow button to select the number of copies for the currently displayed photo.
- 4. Press the (set) button and the following screen will appear.



5. Select 「Yes」 and press the [st] button to confirm; select 「Cancel」 to cancel printing.

#### **Print Index**

You can print all photos in the camera via this function.

 In the PictBridge menu, select <sup>↑</sup>Print Index <sub>→</sub> and the screen as shown below appears.



2. Select  $\lceil$  Yes  $\rfloor$  and press the  $\lceil$  button to confirm; select  $\lceil$  Cancel  $\rfloor$  to cancel printing.

### **Print DPOF Images**

To use DPOF printing, you must select your photos for printing using the DPOF settings beforehand. See "DPOF" section on page 67.


 In the PictBridge menu, select 「Print DPOF Images 」 and the screen as shown below appears.



2. Select 「Yes」 and press the [st] button to confirm; select 「Cancel」 to cancel printing.

#### Exit

Select 「Exit」 to exit the PictBridge menu. At this time, the message 「Remove USB Cable!」 appears on the screen.



Disconnect the USB cable from the camera and printer.

# **APPENDICES**

# Specifications



Design and specifications are subject to change without notice.

Effective Image Sensor Pixels		16.38 Megapixels	
Total Image Sensor Pixels		16.79 Megapixels [1/2.3"CMOS]	
	Focal Length	4.3mm (Wide) — 154.6mm (Tele)	
	[35mm film equivalent]	[24mm (Wide) — 864mm (Tele)]	
	F number	F2.9 (Wide) — F5.7 (Tele)	
Lens	Lens Construction	14 groups 16 elements	
	Optical Zoom	36x	
	Focusing Range	Normal: (Wide) 60cm ~ ∞, (Tele) 290cm ~ ∞; Macro: 5cm ~ ∞ (Wide Only)	
Anti-Handshake		Optical Image Stabilization	
Digital Zoom		4x Digital Zoom (Combined Zoom: 144x)	

Number of Recording Pixels	Still Image	(4:3) 16MP: 4608×3456 10MP: 3648×2736 5MP: 2592×1944 3MP: 2048×1536 0.3MP: 640×480	(3:2) 14MP: 4608×3072	(16:9) 12MP: 4608×2592 2MP: 1920×1080
	Movie	1920×1080 (30fps), 1280×720 (60fps), 1280×720 (30fps), 640×480 (30fps), 320×240 (30fps) High-Speed Movie: 640×480 (120fps)		
Image Compre	ession	Best, Fine, Normal		
DCF, DPOF (Ver1.1) Support		Yes		
File Format	Still Image	Exif 2.3 (JPEG)		
I lie i dilliat	Movie	Movie Format: MOV (H.264), Audio: G.711 [Monaural]		
Shooting Modes		Auto Mode, Program AE, Shutter Priority, Aperture priority, Manual Mode, Face Beautifier, Panorama Mode, Scene Mode [Auto Scene, Landscape, Sport, Beach, Sunset, Fireworks, Night Landscape, Sketch, Snow, Children, ID, Glass, Photo Frame, Panning Shot, Portrait, Fish Eye, Party, Indoor, Leaf, Museum, Night Portrait, Pet Mode-Dog, Pet Mode-Cat, Black and White, Multi Exposure], Movie Mode, Custom Settings		
Detection Features		Face, Smile, Blink, Cat, Dog		
Photo Touch-up		Red-Eye Reduction, Skin Soften, Eye Brightening, Eye Enlargement		

HDR	Yes
Video Panorama	0°~ 360°
LCD Display	3.0 inch (460k Pixels)
ISO Sensitivity	Auto, ISO100/200/400/800/1600/3200
AF Method	Single AF, Multi-AF (TTL 9-point), Object Tracking, Face-Detection
Exposure Metering Method	Artificial Intelligence AE (AiAE), Center-Weighted Average, Spot (Fixed to Center of Frame), Face AE
Exposure Control Method	Program AE (AE-Lock Available), Shutter Prior AE, Aperture Prior AE
Exposure Compensation	±3EV in 1/3 Step Increments
Shutter Speed	1/2000 ~ 30 Seconds
Continuous Shooting	Approx 5 fps (Full Resolution)
Dlayback Madas	Single Photo, Index (9/16 Thumbnails), Slide Show, Date,
Playback Modes	Burst Shooting, Zoom (Approx. x2 ~ x8)
White Balance Control	AWB, Daylight, Cloudy, Fluorescent, Fluorescent CWF, Incandescent, Manual WB, Color Temp. (1900K ~ 10000K)

	Flash Method	Pop-up	
Flash	Flash Modes	Flash Auto, Force Flash, Slow Sync., Slow Sync. + Red-Eye, Red-Eye Reduction	
	Shooting Range	(Wide) Approx. 0.5m ~ 7.5m (ISO 800) (Tele) Approx. 1.2m ~ 4.4m (ISO 800)	
Recording Media		Internal Memory: Approx. 8MB	
		SD/SDHC Card (Up to 32GB Support) [Nonsupport MMC Card]	
Other Features		PictBridge, ExifPrint Support, Multi-Language Support (27 Languages)	
Jacks		AV-OUT/USB 2.0 (Micro 5 pin USB), HDMI (Type D)	
Eye-Fi Support		Yes	
Power		Rechargeable Li-ion Battery LB-060, 3.7V 1100mAh, In-Camera Charging	
Shooting Capability (Battery Performance)		Approx. 210 Shots (Based on CIPA Standards)	
Operation Environment		ment Temperature: 0 ~ 40°C, Humidity: 0 ~ 90%	
Dimensions (W×H×D)		Approx. 112.7×81.6×76.7mm (Based on CIPA Standards)	
Mass		Approx. 416g (Body only)	

# Prompts and Warning Messages

Message	Description	Action
Warning! Battery exhausted.	The camera battery is used up. It is a warning indicating that the camera is going to shut down.	Replace with new batteries. The camera will shut down in 2 seconds.
Lens obstruction, Re-start Camera.	The lens is jammed or some foreign object is preventing the lens from functioning properly.	Turn off the camera and restart it to reset the lens.
Built-in memory error!	An error occurs in internal memory.	Try shutting down the camera and turning it on again. The message will disappear after 2 seconds
Improper alignment. Please try again.	The offset is too big for panorama shooting.	Retry taking the panoramic picture. The message will disappear after 2 seconds.
Warning! Do not turn off your camera during update!	The message appears during the firmware update process.	The message disappears after the camera update and restart.
Remove USB Cable!	Indicates that you can disconnect the USB cable.	The message disappears after you disconnect the USB cable.
Connection Failed!	Failure to connect to your PC, printer, TV (with HDMI).	Remove USB cable and retry connection

Message	Description	Action
Write Protect !	The SD card is locked.	Remove SD card and switch the lever on the side of card to UNLOCK. The message will disappear after 2 seconds.
Card Full!	Indicates that the SD card is full.	Replace SD card with another that has available memory. The message will disappear after 2 seconds.
Memory Full!	Indicates that the camera memory is full.	It disappears after 2 seconds.
Card Error !	During power-on, the SD card cannot be recognized or a read/write error occurs.	Format the SD card. WARNING: Formatting the SD card will erase all data on the card. Copy the data from the SD card to another storage, such as a computer. Otherwise, all data will be erased after the format. The message will disappear after 2 seconds.
Card is not format- ted.	When an error occurs in the SD card, the message "Not Formatted" appears.	Format the SD card. WARNING: Formatting the SD card will erase all data on the card. Copy the data from the SD card to another storage, such as a computer. Otherwise, all data will be erased after the format. The message will disappear after 2 seconds.
Slow access	When a SD card lower than Class 4 is used to record a HD movie, the writing speed will be slower and recording will not continue.	Replace SD card with a higher Class over 4. The message will disappear after 2 seconds.
Cannot write to SD card.	The photo shooting or video recording has been interrupted so recording cannot continue.	Turn off the camera. Then unload and reload the SD card and turn on the camera to retry. Also check if SD card is full or in a locked position.
No Red-Eye De- tected!	Red eyes have not been detected in the image.	The message will disappear after 2 seconds.

Message	Description	Action
This image cannot be edited.	The file format does not support editing or the edited file cannot be edited again.	The message will disappear after 2 seconds.
Exceeded maxi- mum folder number.	Prompt message when the archives or file folders in memory card have reached the maximum (9999 for archives, 999 for file folder).	Copy the data to your PC, format the memory card using the camera.
Too many pictures for quick processing.	During the playback by date, the images exceed specifications so that it is not possible to play by date.	The message disappears after 2 seconds and the camera returns to the normal playback mode.
Unable to recognize files.	The format of the file to be viewed is not supported or the file is corrupted so it cannot be properly read.	This image message disappears only after the file is deleted.
No Picture!	When you press the play button, no image files exist in the camera or memory card.	The message disappears 2 seconds later to return to the photo shooting screen.
No continuous group file.	When you switch from the playback mode to continuous photo mode, there is no continuous group file.	The message disappears after 2 seconds and the camera returns to the normal playback mode.
Protected! Undeletable!	The file is protected. The message appears when you delete it.	Remove SD card and switch the lever on the side of card to UNLOCK. Place back into the camera and try again. The message will disappear after 2 seconds.

# Troubleshooting

Problem	Possible causes	Solution
Camera does not turn on	<ul><li>The battery has been depleted.</li><li>The battery is not inserted correctly.</li></ul>	■ Recharge the battery. ■ Correctly reinstall the battery.
Camera turns off suddenly during operation	■ The batteries have been depleted.	Recharge the battery.
The picture is blurred	Camera shakes while taking a picture.	■ Turn on OIS feature.
Images and video files cannot be saved	<ul><li>The SD memory card is full.</li><li>The memory card is locked.</li></ul>	<ul><li>Use another memory card or delete unnecessary files.</li><li>Unlock the memory card.</li></ul>
Images will not print from the connected printer	<ul> <li>The camera is not connected to the printer correctly.</li> <li>The printer is not PictBridge compatible.</li> <li>The printer is out of paper or ink.</li> </ul>	<ul> <li>Check the connection between the camera and printer.</li> <li>Use a PictBridge compatible printer.</li> <li>Load paper into the printer or replace the ink cartridge in the printer.</li> <li>Remove the jammed paper.</li> </ul>
	■ The printer paper is jammed.	

Problem	Possible Causes	Solution
Saving data to memory card is slow	■ Using a memory card below Class 4 may result in slower recording times.	■ Use a memory card with write Class higher than 4 to improve performance.
Cannot write to the memory card	■ The SD memory card has been locked.	Release the write lock of the memory card or replace with another card.
Too many movies to process	■ The number of pictures or folders in the SD memory card exceed the specifications, so the playback of data folder can not be displayed.	■ Delete unwanted files.



The Kodak trademark and trade dress are used under license from Kodak.

© 2013 by JK Imaging Ltd. All Rights Reserved.

JK Imaging Ltd., 17239 South Main Street, Gardena, CA 90248, USA

JK Imaging Europe, 71 Clarendon road, Watford, WD17 1DS, UK

www.kodakpixpro.com